

BLUE TIGER
SOUND CLEARLY



SoundPODS™

User Manual

www.bluetigerusa.com | 1-800-935-1165

Thank you for purchasing SoundPODS™ by Blue Tiger®. Please review the manual before using this product to ensure your best experience.

Product Features


SoundPODS™ are designed to allow you to listen to music from your phone or Bluetooth® enabled computer or MP3 player. When connected to your phone using Bluetooth®, the SoundPOD will also act as a speakerphone.

The SoundPOD delivers high-quality sound in a small form factor. Our engineers made speaker performance a top priority. You can hear and *feel* the difference in quality!

Getting Familiar with SoundPODS™

SoundPODS™ are designed for simple, hassle-free operation. Below, you will find a diagram that will help you get acquainted with SoundPODS™ design and operation.

Multi-Function Wheel



Bluetooth Pairing Instructions

1. Make certain your SoundPOD is in the "Off" position.
2. Switch the OFF toggle all the way to the right for Bluetooth. Upon activating Bluetooth, the LED light will flash to blue for a few seconds and then begin flashing blue and red.
3. Follow the operating instructions for your phone to allow your device to search for a new Bluetooth connection.
4. Select "soundPODS" on your Bluetooth device list on your phone and when asked, select "Yes" to confirm the connection.
5. If a PIN, Passkey, or Passcode is required, enter "0000."

Operation

Multi-Function Wheel:

+/>> Short press skips to the next song. Long press increases volume. Does not work in Aux mode.

-/<< Short press goes to previous song. Long press decreases volume. Does not work in Aux mode.

▶ || Bluetooth Mode: and will answer and end a phone call when using it as a speaker phone.

MP3/SD Mode: Short press plays or pauses your music.

Understanding the LED Indicator

Green flash: Speaker is in SD/MP3 mode

Green solid: SD/MP3 pause or indicates that the Aux cable is active.


Blue flash: Indicates Bluetooth mode

Red and blue alternating: Indicates pairing mode

Red solid: indicates charging (turns off when fully charged)

Red flash: Low battery indicator

Jack Instructions



Specifications

- ☐ A built in TF Smart decoder allows you to insert a microSD card to play music directly from this storage format.
- ☐ Allows you to plug directly into any source with a 3.5mm stereo cable.
- ☐ Switch to Bluetooth® mode for wireless applications. Use your SoundPOD for speaker phone or for other audio.

NOTE: When using the microSD card feature for playback, your music files must be in .mp3 format and must be saved directly to the root directory, not stored in folders.